

The **LYCON Precision Waxing System** allows professionals to tailor the best waxing services to suit all client needs, skin types & hair growth.

LYCON SINGLE WAX HEATER

HOT WAX

Place broken up LYCON Hot Wax directly into the LYCON Single Wax Heater chamber to melt.

STRIP WAX

LYCON Strip Wax 800g jars. Heat jar in a microwave oven as per directions on the jar, then pour into the LYCON Single Wax Heater.

CAUTION: If heating the plastic jar in a microwave oven make sure to follow the instructions on the jar, taking care not to overheat the plastic jar, as the jar can melt if heated for too long.



LYCOPRO DUO PROFESSIONAL WAX HEATER

HOT WAX

Place broken up LYCON Hot Wax in the provided insert and heat to working temperature. Extra inserts are available to purchase to allow for different hot waxes in your salon.

STRIP WAX

LYCON Strip Wax 800g plastic jars can be placed directly in to the LYCOPRO Duo Professional Wax Heater and heat to working temperature. Do not place the jar in the heater insert provided.

Alternatively, heat the 800ml Strip Wax jar in a microwave according to the heating instructions on the jar. Then pour the wax in to a LYCOPRO Duo Professional Wax Heater Insert. Do not place the jar in the heater insert provided.

CAUTION: If heating the plastic jar in a microwave oven make sure to follow the instructions on the jar, taking care not to overheat the plastic jar, as the jar can melt if heated for too long.



LYCOPRO MINI PROFESSIONAL DIGITAL WAX HEATER

Hot Wax

Place broken up LYCON Hot Wax in the insert provided.

Stip Wax

LYCON 397gm Strip Wax tins can be placed directly in the LYCOPRO MINI Professional Digital Wax Heater. Do not place wax tin in the insert provided.

LYCON 800ml Strip Wax jars can be placed directly in to the heater and heat the jar directly in the heater. Alternatively, you can heat the 800g Strip Wax Jar in the microwave, then place the jar directly in the heater to keep at working temperature. Do not place the jar in the heater insert. You can also pour the microwave heated Strip Wax 800ml jar in to the LYCOPRO MINI Professional Digital Wax Heater Insert

CAUTION: 397gm Stip Wax tins **cannot be heated in the microwave**. If heating the plastic jar in a microwave follow the instructions on the jar, taking care not to overheat the plastic jar, as the jar can melt if heated for too long.



LYCOPRO BABY WAX HEATER

HOT WAX

Place broken up LYCON Hot Wax in to the insert provided.

NOTE FOR ALL HEATERS:

For instruction on heating different waxes please refer to product packaging.

